

Title Goulds Centrifugal Pump

Materials Required

- "PGBU Tailboard Ready Reference Card" (safety)
- Rags
- Shim pack
- Emery cloth
- Magic marker or spray bluing
- Duct tape (for shims)

Tool(s) Required

- Standard mechanics tool box
- Flashlight
- Wire brush
- V-blocks or rollers
- Small straight edge
- Spanner wrench
- Large internal snap ring pliers
- Micrometer set
- Dial indicator set with magnetic base
- Shaft key wrench
- Files

Reference(s)

- Installation, Operation, and Maintenance Instructions; Goulds Vendor Manual
- Product News Bulletin #194; Goulds Pumps

PUMP DISASSEMBLY

- _____ **1. Ensure the pump is safely isolated.**
 - a. De-energize and lock-out the motor breaker.
 - b. Close and tag any suction and discharge valves.
 - c. Drain the pump casing.
- _____ **2. Uncouple the pump from the motor**
 - a. Remove the bolts from the coupling cover.
 - b. Remove the flex grid joining the pump and motor coupling.
 - c. Remove the motor from the base.
- _____ **3. Remove the coupling hub from the pump shaft.**
 - a. Mark the hub position with a felt tip pen.
 - b. Use a soft-face hammer to remove the hub.
- _____ **4. Measure the pump shaft axial and radial run out.**
 - a. Axial shaft movement (thrust) is 0.004" maximum.
 - b. Radial run out is 0.004" TIR maximum.
 - c. Coupling face and hub run out not to exceed .002" maximum.
- _____ **5. Remove the Trico oiler or sightglass from the bearing frame.**
 - a. Remove the oiler bulb
 - b. Unscrew the oiler.
 - c. Explain the method the Trico oiler maintains the oil level in the pump.
- _____ **6. Drain the lubricating oil from the bearing frame.**
 - a. Remove the oil drain plug.
 - b. Wipe the area around the oil drain hole with a clean shop towel.
 - c. Place an oil container under the oil drain hole.
 - d. Replace the oil drain plug.
- _____ **7. Inspect the used oil**
 - a. Bearing wear – metal particles in the oil
 - b. Bearing overheating – burnt oil smell.

_____ 8. **Properly dispose the used oil.**

- a. Per company policy or procedure.

_____ 9. **Remove the pump housing.**

- a. Loosen and remove the frame foot bolts.
- b. Identify and tag any shims found under the frame feet.
- c. Remove the casing bolts.
- d. Tighten the two jacking screws evenly to start working the assembly out of its fit.
- e. Remove the pump housing from the pump assembly.

NOTE: Keep the pull out assembly mounted to the pump base.

_____ 10. **Remove the impeller from the shaft.**

- a. Install the shaft key wrench.
- b. Turn the impeller until the wrench handle is pointing up.
- c. Rotate the impeller rapidly counterclockwise until the wrench bangs against the workbench.

NOTE: It may be necessary to do this several times to loosen the impeller.

- d. Unscrew the impeller.

_____ 11. **Remove the stuffing box cover.**

- a. Remove the seal gland nuts and slide toward the deflector.
- b. Loosen and remove the nuts that hold the stuffing box cover in place.
- c. Remove the stuffing box cover

_____ 12. **Remove the mechanical seal.**

- a. Remove the mechanical seal/sleeve as a unit.

_____ **13. Remove the shaft slinger (deflector).**

- a. Slide the seal gland off the shaft.
- b. Slide the Teflon slinger off the shaft.

NOTE: Due to the interference fit, a slight resistance will be felt when removing the slinger.

_____ **14. Remove the bearing and shaft assembly from the bearing frame.**

- a. Remove the thrust bearing housing clamping bolts.
- b. Tighten the jacking/adjusting screws to start the bearing and shaft assembly out of its fit.

CAUTION: Applying too much pressure to the jacking/adjusting screws can break the thrust bearing housing.

- c. Remove the bearing and shaft assembly by sliding it out by hand after the thrust bearing housing has cleared its fit.

_____ **15. Remove the thrust bearing from the thrust bearing housing.**

- a. Remove the thrust bearing snap ring.
- b. Support the bearing housing and pull the thrust bearing out of its fit.

_____ **16. Remove the thrust and radial bearings from the shaft.**

- a. Depress the lock washer's locking tab (thrust bearing).
- b. Loosen the lock nut with a spanner wrench (thrust bearing).
- c. Unscrew and remove the lock nut and lock washer (thrust bearing).
- d. Remove the bearing using a hydraulic press (thrust and radial bearing) or puller.
 - Support the inner and outer race.
 - Apply even pressure to the pump shaft.

PUMP COMPONENT INSPECTION

- _____ 17. **Clean the pump components.**
 - a. O-ring and snap ring grooves are free of any foreign debris.
 - b. Threaded fasteners have been chased or are free of any burrs/nicks.
 - c. Gasket surfaces are free of any old gasket material.

- _____ 18. **Inspect the pump shaft.**
 - a. The oil seal fit areas, located directly outboard of each bearing fit, are smooth and clean.
 - b. The bearing fit areas are smooth and free of gall marks.
 - c. The stuffing box area is smooth and free of scratches.
 - d. Measure the run out.
 - Place the shaft in V-blocks or rollers.
 - Setup a magnetic base dial indicator.
 - Notify the Supervisor if run out is greater than 0.002".

- _____ 19. **Inspect the stuffing box bore and cover.**
 - a. Clean and check for excessive damage.
 - b. Measure the stuffing box bore concentricity with a dial indicator. (0.003" TIR maximum)

- _____ 20. **Inspect the bearing frame.**
 - a. The bearing frame interior/oil reservoir is clean.
 - b. The radial bearing bore is smooth and not damaged.

- _____ 21. **Inspect the impeller.**
 - a. Replace the impeller if it shows excessive erosion, corrosion, extreme wear, or vane breakage.
 - b. Check the O-ring groove and impeller hub for signs of degradation.

22. Inspect the following pump/mechanical seal components.

- a. Seal faces:
 - Wear patterns,
 - Heat cracking,
 - Cracked hard face,
 - Chipping, flaking, or peeling,
 - Deep wear in the hard face.
- b. O-rings:
 - Swelling or extrusion,
 - Cracks or hardness,
 - Compression set,
 - Cuts or nicks.
- c. Springs:
 - Breakage or cracks,
 - Fatigue (shorter than new springs).
- d. Seal drive:
 - Shiny or dented drive pins or anti-rotation pins,
 - Bent drive pins,
 - Corrosion,
 - Drive screws slipped on the sleeve.
- e. Rotary metal casing:
 - Discoloration of the metal,
 - Corrosion or pitting,
 - Excessive deposits on the body of the seal cage,
 - Set screws cutting into the body,
 - Circular marks on the outer diameter of the body.

PUMP REASSEMBLY

23. Install new thrust and radial bearings.

- a. Press the bearing onto its fit with a hydraulic press (thrust and radial bearing) or slide on after heating with oil bath, oven or induction heater.
 - Support the inner and outer race.
 - Verify that the shaft enters the bearing evenly.
 - Apply even pressure to the pump shaft.
- b. Install the bearing lock washer on the shaft and up against the inner race of the thrust bearing (thrust bearing).
- c. Install and tighten the locknut with a spanner wrench (thrust bearing).
- d. Check to see if one of the lock washer tabs aligns to one of the slots in the locknut after the locknut is firmly tightened (thrust bearing).

CAUTION: Do not loosen the locknut to align a tab to a slot. Continue tightening the locknut until alignment occurs.

- e. Set the lock washer tab firmly in one of the slots of the locknut (thrust bearing).

24. Prepare the thrust bearing housing for bearing installation.

- a. Verify the thrust bearing bore is smooth and not damaged.
- b. Verify the snap ring and O-ring grooves are clean.
- c. Verify the housing interior is clean and free of all foreign material.
- d. Wipe out the bearing frame/oil reservoir with a lint free rag.
- e. Verify the bearing frame vent cap air passages are clean.
- f. Verify the radial bearing oil return hole is clean.
- g. Apply a thin film of lubricant to the thrust bearing housing bore and outer race of the thrust bearing.

25. Install the bearing shaft assembly into the thrust bearing housing.

- a. The bearing housing snap ring is installed with the flat side facing the thrust bearing.

_____ 26. **Install the bearing shaft assembly and thrust bearing housing into the bearing frame.**

- a. Apply a thin film of lubricant to the bore of the thrust bearing housing and the outer race of the thrust bearing.
- b. Guide the bearing and shaft assembly into the bearing frame.

CAUTION: Use care to avoid damaging the bearing frame oil seal.

NOTE: The word “TOP” is casted into the flange of the thrust bearing housing and must be installed face-up.

- c. Install and tighten the bearing housing clamp bolts.
- d. Install the bearing housing jacking screws.

_____ 27. **Verify shaft end play**

- a. Mount a dial indicator to read the shaft (impeller end).
- b. Move the shaft forward and backward observing the indicator movement.
- c. Movement should be within the following tolerances:

Shaft End Play	
	.0011
Double row bearings	.0019
	.0007
Duplex bearings	.0010

_____ 28. **Verify shaft runout**

- a. Mount dial indicator to the pump frame.
- b. Install impeller.
- c. If reading is greater than .002, disassemble and determine the cause.
- d. Remove the impeller.

_____ 29. **Verify bearing frame face runout**

- a. Mount the dial indicator to the shaft.
- b. Rotate the shaft so the indicator rides along the fit for 360°.
- c. If reading is greater than .001, disassemble and determine the cause.

_____ 30. **Install the shaft slinger (deflector).**

- a. Slight force is applied to slide the slinger onto the shaft.

- 31. Position the mechanical seal gland.**
 - a. Gland is inserted over the shaft next to the oil deflector.

- 32. Install the mechanical seal.**
 - a. Position the mechanical seal rotary unit on the shaft sleeve in relation to the stuffing box face.

- 33. Install the stuffing box cover**
 - a. Metal-to-metal contact is made with the frame adapter.
 - b. Install and tighten the stuffing box cover stud nuts.

- 34. Verify the stuffing box cover runout.**
 - a. Mount a dial indicator to the end of the pump shaft.
 - b. Rotate the indicator 360°.
 - c. If reading is greater than .005" determine cause and correct.

- 35. Install the pump impeller and set preliminary clearance.**
 - a. Install a new impeller O-ring.
 - b. Thread the impeller onto the shaft.
 - c. Impeller is butted up against the end of the shaft sleeve.
 - d. Tighten the impeller with the shaft key wrench.
 - e. Back off clamping bolts.
 - f. Holding a .010 feeler gauge between the stuffing box and the impeller, tighten the jacking screws until the impeller is .010 from the stuffing box cover.

- 36. Install the mechanical seal gland.**
 - a. The gland is kept square to its fit during tightening of the fasteners.

- 37. Install the pull-out assembly.**

- a. Clean the casing fit areas.
- b. Verify the gasket seat area is clean and that all traces of the old gasket material are removed.
- c. Install a new case gasket.
- d. Install the pull-out assembly.
- e. Install and tighten the casing bolts in a cross-hatch pattern

CAUTION: The assembly must NOT go metal-to-metal with the casing during fastener tightening.

- f. Install any shims previously removed.
- g. Install and tighten the bearing frame foot bolts.

38. **Install the pump coupling hub.**

- a. Tap with a soft-faced hammer until the hub reaches the reference mark.

39. **Refill the bearing lubricating oil reservoir.**

- a. Check the oiler stem setting and install it on the oiler cup.
- b. Fill and refill the oiler bulb as often as necessary to complete the filling of the bearing frame.

40. **Set the impeller clearance.**

- a. Move the rotating element toward the pump casing until the impeller rubs against the casing.
- b. Relax the jacking screws and tighten the clamping screws to push the entire rotating element toward the casing.
- c. Relax all of the clamping screws and insert a feeler gauge between .008" and .015" between the head of each screw and the face of the bearing housing.
- e. Snug each clamping screw against the feeler gauge.
- f. Remove the feeler gauge.
- g. Tighten the jacking screws evenly to move the impeller away from the casing as much as the clamp screw setting will allow.
- h. Verify the clamping screws are tight.
- i. Tighten the mechanical seal drive collar.
- j. Check that the shaft rotates freely without any rubbing.

PUMP SHAFT ALIGNMENT

41. **Align the pump and motor using the straightedge and feeler gauge method.**

- a. Horizontal and vertical angularity (face) $\pm 0.002"$
- b. Horizontal and vertical offset $\pm 0.005"$

NOTE: Vertical angular misalignment.

- a. Pump coupling diameter = A
- b. Misalignment = B
- c. Distance from pump coupling face to the motor front feet = C
- d. Distance from pump coupling face to the motor rear feet = D

FORMULA: Front feet movement: $F = B/A \times C$

Rear feet movement: $R = B/A \times D$


42. **Take final alignment readings.**

- a. Horizontal and vertical angularity (face) $\pm 0.002"$
- b. Horizontal and vertical offset $\pm 0.005"$

43. **Clean the work area.**

- a. Trash is properly disposed.
- b. Tools are placed back in the tool box.

ATTACHMENT A.



112A	Outboard Bearing
113B	Plug – Oil Fill
122	Shaft – Less Sleeve
134	Bearing Housing
136	Bearing Locknut
168A	Radial Bearing
228	Bearing Frame
319	Sight Glass
332A	Outboard Labyrinth Seal (w/O-rings)
333A	Inboard Labyrinth Seal (w/O-rings)
357K	Gland Stud Nuts
361A	Retaining Ring
370B	Bolt – Frame-to-Adaptor
370C	Clamp Bolt – Bearing Housing
370D	Jack Bolt – Bearing Housing
382	Bearing Lockwasher
400	Coupling Key
408A	Plug – Oil Drain
408H	Plug – Oil Mist Connection
408J	Plug – Oiler
408L	Plug – Oil Cooler Inlet
408M	Plug – Oil Cooler Outlet
418	Jack Bolt – Adaptor-to-Case
423	Jam Nut – Bearing Housing Jack Bolt
496	O-Ring Bearing Housing
497F	O-Ring Outboard Labyrinth Rotor
497G	O-Ring Outboard Labyrinth Stator